

Wireless Mic Instructions

Step 2



1. If necessary, Turn Power Switch On
2. Adjust Volume as Necessary on Amplifier

Wireless Mic Instructions

Step 1



1. Turn Power Switch On
2. On Microphone, Turn Power Switch On
3. Increase Volume "A" on Receiver Above

**Please Return Microphone To Bag.
Thank You!**



Wireless
Microphone
Stored
Here

Connect Laptop

1. Connect Laptop to #2 HDMI Cable (10 feet)
2. Turn TV On using TV Remote.
3. Turn Laptop On.
4. On TV Remote – Push the INPUT button (←see photo) and use Arrow Key on Remote to select HDMI #2 on the TV Screen menu.


Connect DVD Player

1. Turn TV On, using TV Remote.
2. Turn DVD Player On, using DVD Remote.
3. On TV Remote – Push the INPUT button (←see photo) and use Arrow Key on Remote to select HDMI #1 on the TV Screen menu.

TV REMOTE

DVD REMOTE

HDMI #4 CABLE



**TV Up/Down
Control**



INPUT BUTTON

